

1. Introduction
2. Safety precautions
3. Receipt
4. Installation / Operation and maintenance
  - 4.1 Vertical pumps
  - 4.2 Horizontal pumps
  - 4.3 Filter chambers
5. Trouble shooting
6. EC declaration
7. Exploded view and Parts list

## 1. Introduction

Thank you for choosing a Hendor product. Before starting to use this product Hendor strongly recommends to read this owner's manual thoroughly and to follow instructions as closely as possible. In this way your product will function properly for years to come. This owner's manual contains all obligatory safety precautions. The manual should be put at disposal of the end-user of this product and should be present at site in order to allow operator and maintenance crew to use it.

## 2. Safety precautions

The presented symbols are safety alert symbols. Be alert to potential personal injury in case symbols on the product or in this manual are shown.



This label warns for risk of electrical shock when failing to observe.




This label warns about hazards that can cause personal injury, death or major property damage if ignored. Keep in mind that the product can contain chemical liquids.

Carefully read and follow all safety instructions in the manual and on the pump.  
Keep safety labels in good condition. Replace missing or damaged safety labels.

## 2.1 Installation

Pumps and filters should be connected in the prescribed way.

The user always has to consider personal safety and health for himself as well as his direct vicinity.



## 2.2 Electrical



1. Only qualified electricians are allowed to connect pumps according to local regulations of the power supplier.
2. Grounding of the motor should be applied first; failure to ground can cause severe or fatal shock. Do not ground to gas supply lines.
3. Before connecting the motor check corresponding voltage of motor and power supply. Incorrect connection can cause fire or serious damage to the motor and voids warranty. See wiring diagram.
4. Avoid unexpected or accidental starting of the motor by disconnecting and locking out power supply.
5. In case of repair and maintenance disconnect and lock out power supply.
6. Do not point a jet of water at the motor to avoid personal injury (risk of electrical shock).
7. Check wiring dimensions according to the power of the motor.
8. Check fuses on the power supply connection.
9. Thermal overload switch should be used on the connection to the pump. The current overload is adjusted to the value of the motor name plate including +10%.
10. Do avoid damage to the cord line by not hoisting the pump by the cord line and be sure the cord line is not jammed; avoid sharp edges.
11. General rule for Hendor pump shaft rotation: Always run clockwise (CW), looking at cooling fan side.  
Direction of rotation is also indicated on the motor by arrow.

## 2.3 Checking direction of rotation



**Vertical pumps:** Always check direction of rotation **outside** the liquid.

**Horizontal pumps:** Always check the direction of rotation **flooded** with liquid.

Briefly switching on the power will show direction of rotation, looking at cooling fan side. Ignoring these recommendations will damage the pump severely.

## 2.4 Plumbing



1. Connections to the pump and filter should be provided with reliable, persistent materials.
2. Where hoses are used, take care of correct hose clamps.
3. Use the right O-rings for connections.
4. Pipes and hoses should be internally cleared of any obstructions.
5. Check tightness of connections before starting up.
6. Thermoplastic components will not tolerate any plumbing stress.
7. Plumbing should be properly aligned and supported to prevent distortion and damage of parts.
8. Leave enough space for easy access and/or maintenance.
9. Keep position of pump away from any heaters or heater coils.
10. Pumps and filters should be mounted on a sturdy base.


## 3. Receipt

At receipt of the product the identity of the product (by checking name plate data), the completeness of delivery as well as absence of visible damage should be ascertained. The end-user or his representative must ascertain the match of material specification and specific liquid used. Any problems arising from these checks should be made in writing and preferably signed by the forwarding agent as evidence.


## 4.1 Vertical pumps

### 4.1.1 Installation

Take notice of enough bottom clearance at the suction side of vertical pumps.  
See recommendations for bottom clearance.  
Hendor vertical pumps are designed for in-tank installation.  
Out-of-tank models are optional and require special installation instructions.



- 1 maximum liquid level
- 2 normal working level
- 3 minimal starting level
- 4 pump A stops pumping
- 5 pump B will continue to work  
(provided it is not switched off intermittently)
- 6 pump B stops pumping



### 4.1.2 Operation and maintenance

These type of pumps are capable of running dry. At start up the pump should be **checked for direction of rotation outside** the liquid.  
Contaminated strainers if mounted can reduce performance and should be cleaned regularly.

#### Regular pump inspection

During operation all pumps should be checked regularly. Check flow, pressure, manometer indication, pipe work, hoses, hose clamps and absorbed power by monitoring amperage of the motor. Pumps should be fitted with thermal overload switch. Check pumps for any unusual noise or vibration (this may indicate the moment of maintenance).



#### Maintenance precautions

To avoid dangerous or fatal electric shock hazard and to avoid injury from starting the motor unexpectedly, disconnect and lock out power supply to the motor. Always use genuine parts to assure good performance. When taking pump apart check for sequence of disassembly and reassembly. After having completed maintenance or repair, follow safety and installation instructions.

### 4.1.3 Dismantling and reassembly

For efficient maintenance of Hendor vertical pumps, **some special tools** are available (see page 4).



#### General precautions prior to dismantling

- always disconnect electric cables.
- disconnect discharge pipe.
- watch remaining liquid in pump housing.
- do work on a clean bench.

When ordering Hendor parts always quote **pump type** and **serial number**.

#### Dismantling

- remove drip cover (if applicable).
- remove fan cover.
- remove cooling fan by applying two screwdrivers.
- remove sealing ring and locking ring.
- turn pump upside down.
- remove volute cover (by turning clockwise).
- secure shaft end against rotation and loosen impeller (turning anti-clockwise) by using impeller key.

#### Series D90

- take off wiring casing of motor by removing 3 bolts; mind not to damage stator wiring!
- unscrew 4 screws that are accessible for removing pump house
- take off pump house
- loosen shaft protection pipe (turning anti-clockwise)

#### Other series

- remove bolts/nuts that connect motor to pump housing.
- take off pump housing completely.
- loosen impeller-shaft protection pipe (if applicable).

## Electric Motor

All motors are fitted with standard ball bearings.

- by removing rear-end and front-end cover, bearings are accessible.
- rear bearing can be taken off by standard puller.
- front bearing is only accessible after taking out spring ring and removing front shield.
- front bearing of vertical pump motors can only be taken off by applying special Hendor bearing puller.

## Replacing worn or damaged parts

Dismounting and refitting should be carried out very carefully.

## Assembling motor is done in reverse order

Ensure free rotation and check end play of the shaft of vertical pumps at 0,03 mm maximum.


## Assembly

- refit all parts in reverse order.
- prior to mounting volute cover measure distance between top of impeller and bottom of volute cover; this dimension should be in range of 1-2 mm.

Prior to operation of the pump check direction of rotation as indicated by arrow on the motor.

Motor shaft rotation is clockwise, viewed from top of the motor. Testing the rotation of the shaft has to be done outside the liquid; running the pump backwards may loosen the impeller and damage the pump.

## Special tools



	For disassembly of	Use	Pump type	Article number
1	Suction extension pipe (if applicable)	Wrench	All types	9999-000-000-037
2	Strainer (if applicable)			
	Flat strainer	Grip	D17*	9011-000-001-499
	High strainer	Radius key	All types	9062-600-999-002
3	Pump house cover	Grip	D9*/D110/D12*	9011-000-001-551
		Grip	D17*	9011-000-001-499
		Pen key	D2**	9063-623-100-250
4	Impellor	Grip	D9*/D110/D12*	9011-000-001-551
		Grip	D17*	9011-000-001-499
		and Impellor key		9011-891-001-080
		Pen key	D2*	9063-623-100-250
		and Impellor key		9011-891-001-080
5	Motor	Toolbit M4	0,12 - 0,18 - 0,25 kW	9999-000-000-020
		Toolbit M5	0,37 .. 2,2 kW	9999-000-000-021
		Toolbit M6	3 .. 9 kW	9999-000-000-047
6	Motor bearings	Complete bearing puller set	All types	9999-000-000-031
		Bearing puller	D9* only	9999-000-000-023
		Bearing puller	D110 only	9999-000-000-024
		Bearing puller	D12*/D170/D2* only	9999-000-000-025

	PU Paint	0.25L tin (Hendor brown)	All motors	9999-000-000-041
--	----------	--------------------------	------------	------------------

## 4.2 Horizontal Pumps

### 4.2.1 Installation

Horizontal magnetic drive & seal pumps are very sensitive to suction conditions. Many pump problems are caused by poor suction conditions. The bigger the pump and the higher the temperature, the more important the general hydraulic guidelines should be applied. Always try to respect the basic rules for liquid velocity  $v$  (m/s).

We recommend for Suction side  $v = 1 - 2$  m/s; Discharge side  $v = 1,5 - 3$  m/s

Flow l/h	Inner pipe diameter (mm)								
	15	20	25	32	40	50	65	80	100
Velocity (m/s) at given flow (l/h)									
1000	1,57	0,88	0,57						
2000	3,15	1,77	1,13	0,69					
4000	6,29	3,54	2,26	1,38	0,88				
6000		5,31	3,4	2,07	1,33				
8000			4,53	2,76	1,77	1,13			
10000			5,66	3,46	2,21	1,42	0,84		
15000				5,18	3,32	2,12	1,26	0,83	
20000				6,91	4,42	2,83	1,68	1,11	
30000				10,4	6,63	4,25	2,51	1,66	1,1
40000					8,85	5,66	3,35	2,21	1,4

### Golden rules for proper pipe work

1. Keep suction pipe work as short as possible.
2. Increase pipe size on suction side by at least one pipe diameter for longer suction pipe and/or higher temperature.
3. Use eccentric adaptors at varying diameters to prevent air pockets.
4. Avoid elbows, bends and fittings at suction side. When unavoidable keep fittings at a distance of 10 times pipe diameter away from pump inlet.
5. Pipe work should slope up towards pump to prevent air pockets.
6. Pipe work should be completely leak free.
7. Support pipe work near to pump to prevent stress on plumbing.
8. Allow sufficient liquid level to prevent air intake on suction side.
9. Use generously oversized strainer in case of foreign particles.
10. Use siphon breaker when priming over top of tank.
11. Never throttle pump on suction side.
12. In case of doubt consult Hendor for proper sizing and NPSH calculation.

### 4.2.2 Operation and maintenance

Magnetic drive pumps. How it works?

Driver (motor) and impeller (driven) are physically separated by a shell.

Pump part (wet end) is completely sealed.

Power transmission is established by magnetic force between motor shaft and impeller.

Bearings are lubricated and cooled by liquid itself.

Mechanical seal pumps. How it works?

Impeller is directly attached to the motor shaft by shaft coupling.

Mechanical seal on pump shaft prevents liquid from coming out.

Mechanical seal is lubricated and cooled by liquid itself.

These type of pumps are not self priming and not designed to run dry. Optional priming chambers and dry run protection devices are available.

#### Initial start-up

1. Check for direction of rotation before start-up by shortly switching on/off.

Priming instructions at **flooded suction**:

2. Open all valves on suction and discharge side.
3. At start up the pump always should be flooded with liquid to prevent any damage on bearings.
4. These type of pumps are not self priming. Therefore liquid level in the bath should be ample above entrance level of the pump.
5. Start the pump when no air remains in the pump.
6. When pumping liquid with higher density than water, start up with almost closed discharge valve to reduce power consumption.

Priming instructions at **non flooded suction**:

2. Ensure entrance of suction pipe is in liquid.
3. Slowly fill pump casing and suction pipe. Use discharge connection to fill.
4. Check if pump is free of air.
5. Close discharge valve and start the pump.
6. Wait until pump is building up pressure, and slowly open discharge valve.

Restart after power failure: Check if the pump is able to prime again. Suction pipe and pump housing should be filled.


### 4.2.3 Dismantling and reassembly

#### 4.2.3.1 Magnetic drive pumps



##### General precautions prior to dismantling

- always drain liquid from pump.
- disconnect all necessary electric cables or use switch on pump.
- disconnect suction and discharge piping (watch spilling liquid).
- do work on a clean bench.



When ordering Hendor parts always quote Pump Type and Serial Number.

##### Dismantling

- remove bolts from pump casing.
- take out impeller and impeller shell; mind strong magnetic force.

##### Replacing worn or damaged wet end parts

##### Series M10..M15

- rear static bearing is easy to replace.
- take ceramic shaft out of casing and replace it.
- rotating bushing is molded into impeller; replacing only possible by exchanging complete impeller.

##### Series MX60..MX120 and M110..M400

- static bearings cannot be replaced (heat shrunk); when damaged replace complete part.
- rotating bearings are mounted by thread; front right-handed thread ; rear left-handed thread.

##### General description of dismantling a drive magnet

- loosen hex. screws through hole in bracket.
- by means of a lever drive magnet down the shaft; mind strong magnetic force.
- check for remaining metal particles on the magnet and remove them.

##### General description of mounting a drive magnet

- slightly grease shaft of motor.
- replace drive magnet on shaft by hand watching position of key.
- ensure that drive magnet goes up to shaft end (when using a hammer, be sure motor bearings are not damaged).
- secure hex. screws.

##### Assembly

- mount impeller shell.
- put impeller into shell; mind strong magnetic force.
- place O-ring and put pump casing into place.
- mount bolts and tighten them crosswise.


After assembly always check for free rotation by hand. Verify direction of rotation indicated by arrow on pump/motor prior to regular operation.

#### 4.2.3.2 Mechanical seal pumps S55 .. S300-PP



##### General precautions prior to dismantling

- always drain liquid from pump.
- disconnect electric cables or use switch on pump.
- disconnect suction and discharge piping.
- do work on a clean bench.



When ordering Hendor parts always quote **pump type** and **serial number**.

##### Dismantling

- remove bolts from pump casing.
- take off SS plate and pump casing.
- turn safety guard so that hex. screw on coupling is accessible.
- loosen front screw in coupling (pump side).
- take out impeller together with rotating parts of mechanical seal.

##### Replacing worn or damaged parts

- rear static seal ring is easy to replace; mind position of seal ring according to locking pin; always renew O-rings after removing parts.
- take off rotating part; mind position of coil and hook; at replacing seal ring do position O-ring, coil and hook.

- put back cover including static seal ring in place against steel bracket; mind upright position of supply channel for seal.
- place flat rubber gasket in position.
- put a spacer (thickness 2 mm) between back cover and steel bracket (adjusting pre-load on seal).
- put impeller back into position; mind correct position of all rotating parts.
- push impeller firmly as far as possible; hold that position and secure front hex. screw in coupling.
- remove spacer from back cover.
- put pump casing and SS plate back into place.
- mount bolts and tighten them gradually.
- turn safety guard so that holes are pointing downwards (drain in case of leakage).

Check for free rotation by turning cooling fan by hand.

Prior to operation of the pump check direction of rotation as indicated by arrow on the motor.

Testing the rotation has to be done flooded with liquid.

## 4.3 Filter chambers

### 4.3.1 Installation

Following rules should be respected when installing *filter chambers*:

Bottom of filter chamber (by preference) is placed at the same height as bath level; this will ensure an easy medium change and prevents unwanted emptying of tank.

1. Maximum pressure should not exceed indication on dial of manometer.
2. Maximum allowable pressure at temperature range is indicated on top of filter chamber.
3. Adjust diameter of in- and outlet of the filter to required capacity of the system.
4. Return pipe from filter chamber should be placed as far as possible from pump inlet in order to promote good bath movement.
5. Filter chamber 362 has a tiltable lid. Position of lid can be changed by positioning top ring (304).

### 4.3.2 Operation and Maintenance

#### Maximum pressure in filter chamber

The maximum pressure in Hendor filter chamber should not exceed the engraved value on top of the cover plate.

#### Pressure gauge

A pressure gauge is fitted on most Hendor filter chambers. An anti-freeze filled chamber above a membrane separates the pressure gauge from the process liquid. During normal operation the filter chamber regularly should be inspected for flow (dial indication on gauge).

**If pressure on manometer is less than usual**, the chamber below the manometer should be refilled.

Topping up manometer liquid:

After removing gauge (328) and air release screw, top up casing (327) with anti-freeze.

When assembling gauge (mind O-ring 335) liquid must show up.

Put back air release screw into casing and tighten it.

If liquid does not show up repeat procedure here above. If still no liquid shows up the membrane should be replaced.

Remove gauge (328), unscrew 4 screws, take off the lid (327), replace membrane (326), refit 4 screws lightly, holding down the membrane with unsharp object through lid, tighten 4 screws and repeat above mentioned procedure.

**If pressure on the dial of the gauge is not coming back to zero**, when the pump is switched off, there may exist a difference of pressure between inside gauge and open air. To correct dial indication cut off the top of the rubber cap on top of the gauge.

### 4.3.3 Dismantling and reassembly

#### Replacement of filter elements

Depending on the type of filter, the filter element(s) should be exchanged reaching a maximum pressure difference of 1-2,5 bar.

#### Sequence of operation

- switch off pump (ensure pump cannot be started unexpectedly).
- close all main taps.
- open drain valve.
- open air release tap to empty filter chamber.
- loosen all star buttons.
- remove or tilt the lid of the filter chamber; sometimes the gasket sticks to the chamber and extra lifting effort is required to remove the lid.

Hendor filter chambers are equipped with cartridges, discs or bags.

After removing the contaminated filter medium it should be disposed off according to environmental guidelines.

Properly install the new filter medium to prevent by-pass of unfiltered liquid.

#### Closing sequence

- check sealing rubber of chamber on distortion.
- close lid
- turn two fixed star button 4 times clockwise.
- tighten remaining star buttons firmly crosswise.
- close drain valve, open main taps and start-up the pump.
- check unit for any leakage.
- after bleeding the unit, close air release tap.



## 5. Trouble shooting

Pump problem	Possible reason - horizontal pump	Possible reason - vertical pump
No liquid flow	2-3-4-5-6-7-8-12-15-22-24-31	4-5-7-8-12-15-17-22-24-28-31
Insufficient liquid flow	1-3-6-8-10-11-13-14-15-16-18-19-20-25-28-29	8-10-13-14-15-16-18-19-20-25-28-29-30
Insufficient pressure	8-10-13-14-15-16-18-20-25-29-30	10-13-14-16-18-30-25-29-30
Rising liquid temperature	8-15-19-25	8-15-18-19
Noisy pump or excessive vibration	1-3-6-13-14-15-20-21-22-23-28-34	9-13-14-15-16-17-21-22-23-32
Motor is overheating	13-15-16-20-21-22-23-24-25-27-28-29-30	15-16-21-22-23-24-25-27
Motor overload activated	20-25-26-28-29-30	22-25-26-29-30
Cracking/deformation	9-34-49	9-34-49
Corrosion	27-50	27-50

Filter problem	Possible reason
No or insufficient liquid flow	8-19-28-38-39-41-42-48
Leakage	39-40-49
Pressure gauge reading not correct	35-36-37-38
High dial indication on pressure gauge	8-42-48
Bad filtering result	33-42-43-45-47
Foam formation in the bath	11-31-46

### System / Pipework

- 1 Suction pipe too long or diameter too small
- 2 Air pocket in suction pipe
- 3 Leak in suction pipe
- 4 Suction pipe or strainer blocked
- 5 Suction height too high
- 6 Air supply close to suction inlet
- 7 Foot valve or suction pipe insufficiently submerged
- 8 Valve in pipework (partly) closed
- 9 Discharge pipe under tension
- 10 Leak in discharge pipe
- 11 Return pipe not submerged (air intake)
- 12 Liquid level in tank too low

### Pump

- 13 Impeller damaged or worn out by abrasives
- 14 Impeller out of balance
- 15 Impeller / volute blocked by foreign matter
- 16 Wrong impeller choice (50 or 60 Hz)
- 17 Volute not immersed sufficiently in the liquid
- 18 Wrong choice of pump size
- 19 Pump is running at very low flow

### Motor

- 20 Wrong direction of rotation
- 21 Cooling fan blocked or loose
- 22 Motor bearings jammed or worn out
- 23 Motor bearings incorrectly installed
- 24 Motor down on a phase
- 25 Incorrect voltage
- 26 Thermal overload setting incorrect
- 27 Insufficient cleaning

### Liquid

- 28 Liquid has crystallised
- 29 Specific gravity of liquid too high
- 30 Viscosity of liquid too high
- 31 Air / gas in liquid
- 32 Abrasive particles in liquid
- 33 Colloidal liquid
- 34 Liquid temperature too high

### Filter

- 35 Not enough anti-freeze in chamber below pressure gauge
- 36 Membrane in chamber below pressure gauge deformed/damaged
- 37 Pressure gauge defect
- 38 Filter chamber insufficiently bled
- 39 Filter chamber not closed properly
- 40 Filter chamber gasket damaged or deformed
- 41 Filter element incorrectly installed
- 42 Filter system element saturated
- 43 Bypass of unfiltered liquid
- 44 Filter medium is too coarse
- 45 Filter material damaged or torn
- 46 Unwashed cartridges used (residues of wetting agents)
- 47 Wrong choice of filter medium
- 48 Wrong choice of micron rating

### Material / Environment

- 49 Wrong choice of pump / o-ring material
- 50 Aggressive environment

## 6. EC-Declaration of conformity

Manufacturer: Hendor Pompen BV  
Address: P.O. box 9  
5530 AA Bladel  
The Netherlands

Herewith we declare, that the product:

### **Pump**

- is in conformity with the provisions of the Machinery Directive, as amended, and with national implementing legislation (Directive 98/37/EC, annex II sub A)
- is in conformity with the provisions of the following other EC directives: Low voltage directive (Directive 73/23/EC)

### **Filter**

- is in conformity with the provisions of the Pressure Equipment Directive PED97/23/EC


Confirmed at Bladel

Signature



Technical Director H.F.G. Bohncke


### Series D90 - PP/PVDF



- 201 Volute
- 202 Volute cover
- 204 Impeller
- 207 Shaft protection pipe
- 211 Electric motor
- 212 O-ring
- 213 Suction extension pipe
- 218 Motor drip cover
- 224 Splash guard
- 703 Connection
- 704 Connection

*option: with suction extension pipe*


### Series D110 - PP



- 201 Volute
- 202 Volute cover
- 203 Strainer
- 204 Impeller
- 206 Discharge pipe
- 207 Shaft protection pipe
- 208 Discharge elbow
- 209 Mounting plate
- 211 Electric motor
- 213 Suction extension pipe
- 216 Fastener kit
- 218 Motor drip cover

*option: with suction extension pipe*


### Series D120 - PP/PVDF



- 201 Volute
- 202 Volute cover
- 204 Impeller
- 207 Shaft protection pipe
- 211 Electric motor
- 212 O-ring
- 213 Suction extension pipe
- 216 Fastener kit
- 218 Motor drip cover
- 703 Connection
- 704 Connection


*option: with suction extension pipe*

### Series D160 - SS316



- 201 Volute
- 204 Impeller
- 205 Impeller screw
- 209 Mounting plate
- 211 Electric motor
- 212 O-ring
- 215 Bracket
- 216 Fastener kit
- 218 Motor drip cover
- 219 Fixation set
- 222 V-ring
- 223 Bearing


### Series D170 - PP/PVDF




- 201 Volute
- 202 Volute cover
- 203 Strainer
- 204 Impeller
- 206 Discharge pipe
- 209 Mounting plate
- 211 Electric motor
- 212 O-ring
- 213 Suction extension pipe
- 216 Fastener kit
- 218 Motor drip cover
- 220 Union nut
- 221 O-ring

economy

reinforced




### Series D200 - PP




- 201 Volute
- 202 Volute cover
- 203 Strainer
- 204 Impeller
- 206 Discharge pipe
- 208 Discharge elbow
- 209 Mounting plate
- 211 Electric motor
- 213 Suction extension pipe
- 216 Fastener kit
- 219 Fastener kit


**Series M10 - M11 - M15 - PP/PVDF**




**Series MX40 - MX60 - MX90 - MX120 - PP/PVDF**




**Series M110 - M150 - M220 - M300 - M400 - PP/PVDF**




**Series S55 - S75 - S110 - S150 - S220 - S300 - PP**




### F-11/12A-K-PP



### 11/12-K-PP




### 21/22-K-PP



- 302 Filter housing  
305 Chassis  
310 O-ring  
314 Fastener kit  
320 Gasket  
321 Cover  
329 Air release valve  
339 O-ring  
361 Seal plug  
375 O-ring kit (all O-rings)  
401 Support rod  
402 Extension bushing  
403 Knob support rod  
600 Pipe work discharge  
701 Connection  
705 Pipe work




## F-31/32A-K/P-PP



- 301 Mounting plate
- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406 O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 701 Connection
- 702 Connection
- 703 Connection


## 31/32A-K/P-S-PP



- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 305 Chassis
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 340 Slurry tank
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406 O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 500 Pipe work suction
- 600 Pipe work discharge
- 701 Connection
- 702 Connection




## F-71/72A-K/P-PP



- 301 Mounting plate
- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406A O-ring
- 406B O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 701 Connection
- 702 Connection
- 703 Connection



## 71/72A-K/P-S-PP




- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 305 Chassis
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 340 Slurry tank
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406A O-ring
- 406B O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 500 Pipe work suction
- 600 Pipe work discharge
- 701 Connection
- 702 Connection

# F-71/72A-B-PP


- 301 Mounting plate
- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 404 O-ring
- 412 Inner cylinder
- 413 Basket
- 414 Sealing
- 701 Connection
- 702 Connection
- 703 Connection





## F-151/152A-K/P-PP


- 301 Mounting plate
- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406A O-ring
- 406B O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 701 Connection
- 702 Connection
- 703 Connection



## 151/152A-K/P-S-PP


- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 305 Chassis
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 334 O-ring
- 335 O-ring
- 340 Slurry tank
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 406A O-ring
- 406B O-ring
- 407 Base disc holder
- 408 Rod disc holder
- 409 Disc
- 410 Top disc holder
- 411 Nut disc holder
- 500 Pipe work suction
- 600 Pipe work discharge
- 701 Connection
- 702 Connection

## F-362A-K/P-PP



- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 306 Pedestal
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 322 Tilt stop
- 323 Handle
- 324 Wheel set
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 331 Tilting set
- 334 O-ring
- 335 O-ring
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 409 Disc
- 410 Top disc holder
- 415 Crown
- 416 Sealing plate
- 600 Pipework discharge
- 701 Connection
- 702 Connection
- 703 Connection

## 362A-K/P-S-PP



- 302 Filter housing
- 303 Bottom ring
- 304 Top ring
- 306 Chassis
- 317 Rod
- 319 Star knob
- 320 Gasket
- 321 Cover
- 322 Tilt stop
- 323 Handle
- 324 Wheel set
- 325 Gauge housing
- 326 Membrane
- 327 Cover gauge housing
- 328 Pressure gauge
- 329 Air release valve
- 331 Tilting set
- 334 O-ring
- 335 O-ring
- 340 Slurry tank
- 350 Assembly pressure gauge
- 375 O-ring kit (all O-rings)
- 400 Filter element
- 401 Support rod
- 402 Extension bushing
- 403 Knob support rod
- 404 O-ring
- 405 Baseplate disc/cartridge
- 409 Disc
- 410 Top disc holder
- 415 Crown
- 416 Sealing plate
- 500 Pipework suction
- 600 Pipework discharge
- 701 Connection
- 702 Connection
- 703 Connection